CHIAYO

Operation manual

DPR-500m

MP3 recorder module



CHIAYO ELECTRONICS CO.,LTD.

DPR-500m MP3 recorder module

Parts and functions



remote control➤

1. LCD display
2. Press to return to previous track, press and hold to fast reverse.
3. Press to play/pause or stop recording. (readable formats: **mp3**, **wav** and **wma**)
4. Press to go to next track, press and hold to fast forward.
5. Press to record.
6. Press to switch repeat modes.
7. Press to stop playing or recording.
8. IR sensor area
9. USB input
10. USB/SD indicator: The LED flashes green during playing and red during recording. It lights red if there is no track to play, lighting green when playing or recording stops.
11. SD card input
12. Power switch/volume control

Operating functions on the panel and the remote

Operating function	On the panel	On the remote
Play/pause	Press ⏯	Press ⏯
Record	Press ● to record and ⏯ or ■ to stop.	Press REC. to record and ⏯ or ■ to stop.
Skip forward	Press ⏭	Press ⏭
Fast forward	Press and hold ⏭	Press and hold ⏭
Skip backward	Press ⏮	Press ⏮
Fast backward	Press and hold ⏮	Press and hold ⏮
Next folder	-	Press ⏭⏭
Previous folder	-	Press ⏮⏮
Track select (#0-9)	-	input track number, then press ⏯
USB/SD switch	-	Press USB/SD
Repeat mode switch (ALL / SINGLE / FOLDER)	Press MODE	Press MODE
Volume control	-	Press Vol+ or Vol-
A-B section play	-	Press A-B to start, again to play section and again to stop
Delete tracks	-	Press DEL to delete track and again to confirm your delete
Mute	-	press MUTE to mute/recover

Note:

- Supports FAT and FAT32 file systems only.
- Supports MP3, WAV and WMA music formats only
- Record track format :MP3; Bit rate: 128kbps; Sampling frequency: 44kHz
- Recordable only when USB/SD is detected.
- Record files will be stored in the RECORD folder of USB/SD.
- The files will be named as ***FILE_001***, ***FILE_002***, ***FILE_003***…etc.
- The name of a deleted track won't be applied to its next one.
- Recordable until ***FILE_999*** appears with LCD displaying "***Num Full***".
- LCD displays ***USB FULL*** or "***SD FULL***" when insufficient memory left.
- LCD displays ***SD LOCK*** if the SD is locked.
- Don't remove the USB/SD during the recording process in case the interrupted track might be damaged.

CHIAYO ELECTRONICS CO.,LTD.

Http://www.chiayo.com.tw｜Email: sales@chiayo.com.tw
Office: 30, Lane 27, Section 4, Jen-Ai Road, Taipei 10685, Taiwan
Tel: 886-2-27415741｜Fax: 886-2-27525242
Factory: 88, Chung-Hsiao Street 2, Chiayi 60080, Taiwan
Tel: 886-5-2711000｜Fax: 886-5-5767611