

KX2 Mounting Installation Notes

CONDUIT BOX INSTALLATION

The KX2 uses a standard 4"x4" electrical junction box. These should be available at most hardware stores or electrical supply stores online (ex. Granger.com)



NOTES:

- A dual gang outlet box will NOT work.
- The KX2 has .38" thick corner tabs, making the KX2 protrude .38" from the front edge of the junction box. Therefore, the electrical box should be mounted flush with the wall stud. Typically wall sheeting materials like drywall are 1/2" or thicker, allowing the KX2 to be flush with the wall sheeting. If the wall sheeting is thinner than .38", the junction box will need to be mounted set back.
- Use #8 – 32 flat head screws.
- Box should be 1.5" minimum depth.

